




2686 Highway 92 - Oskaloosa, IA 52577

phone: 641.673.0468 - fax: 641.673.4168

www.kelderman.com

2010-2012 Ram 2500-3500 Pickup Steering Stabilizer



1. Remove (2) middle bolts from front differential cover.
2. Locate the center mounting bracket ("K" bracket) and backing clamp.
3. Fasten the brackets together with the (4) 7/16" x 2" bolts and the (2) differential bolts.
4. Locate the shock mounting brackets. The passenger side mount fastens with supplied U-bolts. The driver's side mounts with the steering linkage factory nuts.
5. Locate the steering stabilizer shocks and connecting plate. Each shock has (2) spacers in the hiem ends. The ram ends use short spacers and the shock body end uses a short spacer on top and tall spacer on bottom. Use the 1/2" x 2" bolts on the outer ends and the 1/2" x 3" on the shock body hiem ends.

