

Ram 4500/5500 60" cab to axle sway bar install instructions



1. The Ram 4500/5500 chassis cabs have a different exhaust than the 84" and longer chassis. This requires a different end link set up than shown in the instructions provided in the kit. The 60" kit uses longer endlinks and they attach to the side of the frame. Use the pictures below to see which hole to use. You will want to drill the hole out to 1/2". Make sure to use the machined washer on the outside of the bushing. Torque the 1/2" bolts to 85 ft/lbs.

